

## Accessorize the RICOH GR IV!

Genuine GR accessories expand your range of shooting

### RICOH GF-2 External Flash

This compact, slim flash features a super-compact body for outstanding portability, small enough to carry in a pocket while attached to the GR IV camera. When the GR IV is set the ISO Auto Flash mode, the GF-2 allows the camera to automatically adjust its guide-number and ISO sensitivity settings according to the subject's distance. This flash mode enhances the GR IV's snapshot operations in casual flash photography.



### RICOH DB-120 Rechargeable Battery

High-capacity rechargeable lithium-ion battery for the RICOH GR IV. Record approximately 250 shots on a single charge.



### RICOH BJ-12 Battery Charger

Battery charger exclusively designed for the RICOH DB-120 Battery. Can recharge up two batteries simultaneously.

*\*Use the Battery Charger BJ-12 with USB cable provided with the camera.*

### RICOH GA-3 Lens Adapter & GW-4 Wide Conversion Lens

Use the GA-3 Lens Adapter to attach φ49mm filters or the GW-4 Wide Conversion Lens to the GR IV camera body.

The GW-4 Wide Conversion lens widens the angle to an equivalent focal length of 21mm (equivalent in 35mm format).



### RICOH GN-3 (DG) Ring Cap

Enhance the GR IV's appearance with this metallic-finished ring cap



### RICOH GS-4 Finger Strap

Genuine-leather finger strap comfortably fits the user's hand for improved camera hold during carrying



### RICOH GK-2 Metal Hotshoe Cover *(available February 2026)*

Metallic, dark gray hotshoe cover made of high-quality stainless alloy



### RICOH GC-11 & GC-12 Soft Cases

Stylish leather cases offer added protection for the camera